


VIBRO CHAMP FRONT AND BACKPANEL



FENDER MUSICAL INSTRUMENTS

CAUTION

SPEAKER, 6 WATTS RMS

TO PREVENT ELECTRIC SHOCK
DO NOT REMOVE CHASSIS.
NO USER SERVICEABLE
PARTS INSIDE. REFER
SERVICING TO QUALIFIED
PERSONNEL ONLY.



4 Ohms

↙ FUSE 1A 230V

VIBRATO PEDAL

1A 230V
50 Hz
CAUTION
DISCONNECT POWER SUPPLY
BEFORE CHANGING FUSE
MADE IN GERMANY



20072007