



DC Voltages may vary by 10% depending on component tolerances.

If the amplifier generates noise in operation, although the wiring is correct, then swap the wires going from the OT to the plates of the power tubes.

V1 - V3: ECC83  
 V4 - V5: KT66  
 V6: GZ34

TR1: Welter N6-US with H96oF  
 TR2: Welter Ü-JTM45  
 CH1: Welter DR1

|                       |                 |
|-----------------------|-----------------|
| <b>JTM45 - Model</b>  |                 |
| Circuit Diagram       |                 |
| BERND BRIESKORN, 2017 | Version         |
|                       | 1.5 275-07-2016 |